

## English

### Correction

Page 27 How to use the Quick Setup

**Incorrect**

3 Press I/⏻.

**Correct**

3 Press I/⏻.

Press FUNCTION to select "DVD."

Page 42 Notes

**Incorrect**

- Shuffle Play is cancelled when you eject the disc. The play mode changes in the following sequence:  
SHUFFLE (ALL) → CONTINUE (ALL)  
SHUFFLE (ONE) → CONTINUE (ONE)  
SHUFFLE (ALBUM) → CONTINUE (ALBUM)

**Correct**

This note is not applicable to this unit.

Page 91 Video section

**Incorrect**

Outputs Video: 1 Vp-p 75 ohms

**Correct**

Outputs Video: 1 Vp-p 75 ohms

S VIDEO:

Y: 1 Vp-p 75 ohms

C: 0.286 Vp-p 75 ohms

COMPONENT:

Y: 1 Vp-p 75 ohms

PB/CB, PR/CR: 0.65 Vp-p 75 ohms

## Français

### Correction

Page 27 Comment utiliser la Configuration rapide

**Incorrect**

3 Appuyez sur I/⏻.

**Correct**

3 Appuyez sur I/⏻.

Appuyez sur FUNCTION pour sélectionner « DVD ».

Page 44 Remarques

**Incorrect**

- La lecture aléatoire est annulée quand vous éjectez le disque. Le mode de lecture change dans l'ordre suivant :  
ALEATOIRE (TOIS) → LECTURE CONTINUE (TOIS)  
ALEATOIRE (UN) → LECTURE CONTINUE (UN)  
ALEATOIRE (ALBUM) → LECTURE CONTINUE (ALBUM)

**Correct**

Cette remarque ne s'applique pas à cette chaîne.

Page 97 Section vidéo

**Incorrect**

Sorties Vidéo: 1 Vp-p 75 ohms

**Correct**

Sorties Vidéo: 1 Vp-p 75 ohms

S VIDEO:

Y: 1 Vp-p 75 ohms

C: 0.286 Vp-p 75 ohms

COMPONENT:

Y: 1 Vp-p 75 ohms

PB/CB, PR/CR: 0,65 Vp-p 75 ohms