



Screen Surface
Surface de l'écran
Superficie de la pantalla

(KP-57/65WV600 / KP-57/65WV700)

CAUTION

To clean the screen of your projection TV, please use only a clean, soft cloth lightly dampened with water. Stubborn stains such as fingerprints can be removed with a clean, soft cloth slightly dampened with a solution of mild soap and warm water. Never use strong solvents (such as thinner, benzene or ammonia), or abrasive cleaning solutions to clean your TV screen.

ATTENTION

Pour nettoyer l'écran de votre télévision à projection, veuillez n'utiliser qu'un chiffon doux et propre légèrement humecté d'eau. Les taches rebelles, telles que les empreintes de doigt, peuvent être éliminées au moyen d'un chiffon doux et propre légèrement humecté d'une solution de savon doux et d'eau tiède. N'utilisez jamais de solvants forts (tels que du diluant, de l'ammoniac ou benzène) ou des solutions de nettoyage abrasives pour nettoyer votre écran de télévision.

PRECAUCIÓN

Para limpiar la pantalla de su televisor de proyección, por favor use sólo un paño ligeramente humedecido con agua. Puede eliminar las manchas difíciles, como huellas digitales, con un paño limpio y suave ligeramente humedecido con una solución de agua tibia y jabón suave. Nunca limpie la pantalla de su televisor con solventes fuertes (como solventes, benceno o amoníaco) ni soluciones limpiadoras abrasivas.