

Memory Stick® Media Compatibility Information for Alpha Cameras

How to Use This Chart:

Locate your camera model on the left-hand side and then scan along the top row for your memory card model. If the camera or memory card you are looking for is not on the page, continue checking later pages in the document.

Important Information:

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.
- The recording time and the number of still images that can be recorded will vary by device. Refer to the instruction manual supplied with your camera for more information.
- Attach a dedicated adapter to use Memory Stick Duo™ media in a slot for standard size media.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions. Refer to the back of the packaging for the minimum guaranteed capacity. [Click here to view the Memory Stick media user capacity chart.](#)
- This compatibility chart and specifications are subject to change without notice.

Notes:

*1	This media is not compatible with XAVC S movie mode.
*2	TransferJet function is not available for use with this product.
*3	A dedicated adapter must be attached to use the Memory Stick Micro® media .
*4	This media cannot be used when Secure Access is set to ON. Please switch off Secure Access function, using the software Memory Media Utility.
*5	Mirroring function is not available for use with this product.
*6	This Memory Stick® may not be able to record or play video.
*7	Use a Memory Stick®; 1GB or over when shooting video.
*8	This media is not compatible with HD movie mode.
*9	This media is not compatible with simultaneous movie recording.
*10	This media is not compatible with simultaneous movie recording in Standard mode.
*11	This media cannot be used in "Standard mode" as file system is different.
*12	Use the AD-MSCF1 Memory Stick®; adaptor for Memory Stick Duo®; media.
*13	The recording failure of sound may occur by pushing the DIVIDE button during recording.
*14	The Transmission speed may not be faster when using Memory Stick PRO®; (High Speed/Mark2) and Memory Stick PRO-HG®;.
*15	The recording failure of sound may briefly occur while pre-recording buffer is activated.

Memory Stick

Camera	MS-A4GU2	MS-A512	MS-A8G	MS-A8GN	MS-A8GU2	MS-EX1G	MS-EX2G	MS-EX4G	MS-HX16A	MS-HX16AG	MS-HX16B
DSC-RX100M3	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*1	OK*1	OK*1	OK*1	OK*1	OK*1
DSC-H400	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX400V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX60V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W800	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W810	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W830	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX220	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX350	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-H300	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-RX10	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-RX100M2	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-RX1R	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-H200	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX300	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX50V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-TF1	OK*8	OK*8	OK*8	OK*8	OK*8	NA	NA	NA	NA	NA	NA
DSC-TX30	OK*8	OK*8	OK*8	OK*8	OK*8	NA	NA	NA	NA	NA	NA
DSC-W710	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W730	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX200	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX300	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX60	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX80	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-RX1	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-RX100	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-H90	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX10V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX200V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX20V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX30V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-TX20	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-TX200V	OK*8	OK*8	OK*8	OK*8	OK*8	NA	NA	NA	NA	NA	NA
DSC-TX66	OK*8	OK*8	OK*8	OK*8	OK*8	NA	NA	NA	NA	NA	NA
DSC-W610	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W620	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W630	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W650	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W670	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-W690	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX100	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX150	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX50	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-WX70	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-TX55	OK*8	OK*8	OK*8	OK*8	OK*8	NA	NA	NA	NA	NA	NA
DSC-H70	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX100V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX7V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-HX9V	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-J10	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-T110	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-T110D	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK
DSC-TX10	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK*3*8	OK	OK	OK	OK	OK	OK

Memory Stick									
Camera	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-RX100M3	OK*1	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-H400	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX400V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX60V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W800	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W810	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W830	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX220	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX350	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-H300	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-RX10	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-RX100M2	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-RX1R	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-H200	NA	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX300	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX50V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-TF1	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-TX30	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-W710	NA	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W730	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX200	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX300	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX60	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX80	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-RX1	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-RX100	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-H90	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX10V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX200V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-HX20V	OK	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX30V	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-TX20	NA	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX200V	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-TX66	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-W610	NA	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W620	NA	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W630	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W650	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W670	NA	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-W690	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX100	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX150	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX50	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-WX70	OK	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8	OK*8
DSC-TX55	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-H70	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX100V	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX7V	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX9V	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-J10	NA	NA	NA	NA	NA	NA	NA	NA	NA
DSC-T110	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-T110D	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX10	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK

Memory Stick

Camera	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-TX100V	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W510	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W530	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W550	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W560	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W570	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W570D	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-WX10	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-WX7	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-WX9	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-T99	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-T99D	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX9	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-WX5	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-H55	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX5V	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-S2000	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-S2100	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX5	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX7	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W310	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W320	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W330	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W350	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W370	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W390	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-TX1	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-WX1	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-G3	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-H20	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-HX1	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-S930	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-S950	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-S980	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-T90	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-T900	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W180	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W190	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W210	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W215	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W220	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W230	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W270	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W275	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK
DSC-W290	-	OK	OK	OK*8	OK*8	OK	OK	OK*8	OK